

F00RJ00220 Injector Solenoid Valve O-ring Technical Instruction

SKU: G1M1F00RJ00220

COMMON RAIL — INJECTOR PART



COMMON RAIL
INJECTOR PART



F00RJ00220 Injector Solenoid Valve O-ring Technical Instruction

1. F00RJ00220 Injector Solenoid Valve O-ring Introduction.....	2
1.1. F00RJ00220 Injector Solenoid Valve O-ring Basic Information.....	2
1.2. F00RJ00220 Injector Solenoid Valve O-ring Common Part Number.....	2
1.3. F00RJ00220 Injector Solenoid Valve O-ring Parameters.....	3
1.4. F00RJ00220 Injector Solenoid Valve O-ring Specifications And Dimensions.....	3
1.5. F00RJ00220 Injector Solenoid Valve O-ring Quality Control.....	3
1.6. F00RJ00220 Injector Solenoid Valve O-ring Customization Service.....	4
1.7. F00RJ00220 Injector Solenoid Valve O-ring Parts List And Packaging Size	4
1.8. F00RJ00220 Injector Solenoid Valve O-ring Testing Standards and Certificates.....	6
1.9. F00RJ00220 Injector Solenoid Valve O-ring Warranty Instructions.....	6
1.10. F00RJ00220 Injector Solenoid Valve O-ring Manufacturer.....	7
2. F00RJ00220 Injector Solenoid Valve O-ring Technical Support	7
2.1. F00RJ00220 Injector Solenoid Valve O-ring Utilized Location	7
2.2. F00RJ00220 Injector Solenoid Valve O-ring Installation Precautions	8
2.3. Reasons for F00RJ00220 Injector Solenoid Valve O-ring Not Working Normally	9
2.4. Causes of F00RJ00220 Injector Solenoid Valve O-ring Being Damaged	9
2.5. F00RJ00220 Injector Solenoid Valve O-ring Storage Standards.....	10
2.6. F00RJ00220 Injector Solenoid Valve O-ring Technical Support Obtaining Methods	10
3. F00RJ00220 Injector Solenoid Valve O-ring Purchase And Delivery.....	10
3.1. F00RJ00220 Injector Solenoid Valve O-ring Purchase And Payment Term.....	10
3.2. F00RJ00220 Injector Solenoid Valve O-ring Main Sales Markets	11
3.3. F00RJ00220 Injector Solenoid Valve O-ring Declaration Requirements	11
3.4. F00RJ00220 Injector Solenoid Valve O-ring Shipping Ways.....	11
3.5. F00RJ00220 Injector Solenoid Valve O-ring Delivery Time.....	11
3.6. F00RJ00220 Injector Solenoid Valve O-ring Logistics Time for Destination Out of China's Areas...11	
3.7. F00RJ00220 Injector Solenoid Valve O-ring Shipping Package	12
4. Company Information.....	12
4.1. Company Introduction.....	13
4.2. Contact Information	13
5. Copyright Statement.....	14

F00RJ00220 Injector Solenoid Valve O-ring Technical Instruction

1. F00RJ00220 Injector Solenoid Valve O-ring Introduction

1.1. F00RJ00220 Injector Solenoid Valve O-ring Basic Information

Title	F00RJ00220 Injector Solenoid Valve O-ring	Quality
SKU	G1M1F00RJ00220	China Made New

1.2. F00RJ00220 Injector Solenoid Valve O-ring Common Part Number

1) Injector Solenoid Valve O-ring Applicable Injector Model

Injector Part Number	Injector Part Number	Injector Part Number	Injector Part Number	Injector Part Number
0445120003	0445120004	0445120006	0445120007	0445120008
0445120009	0445120010	0445120012	0445120013	0445120014
0445120015	0445120016	0445120017	0445120018	0445120019
0445120020	0445120025	0445120028	0445120029	0445120031
0445120032	0445120035	0445120037	0445120038	0445120040
0445120041	0445120043	0445120046	0445120058	0445120059
0445120060	0445120069	0445120070	0445120077	0445120079
0445120084	0445120085	0445120089	0445120094	0445120095
0445120097	0445120103	0445120109	0445120112	0445120113
0445120114	0445120115	0445120120	0445120121	0445120122
0445120123	0445120125	0445120132	0445120133	0445120140
0445120144	0445120151	0445120152	0445120159	0445120208
0445120209	0445120210	0445120211	0445120212	0445120231
0445120236	0445120237	0445120238	0445120239	0445120240
0445120041	0445120243	0445120250	0445120251	0445120252
0445120253	0445120254	0445120255	0445120256	0445120272
0445120273	0445120326	0445120328	0445120330	0445120455
0986435503	0986435505	0986435508	0986435509	0986435515
0986435522	0986435523	0986435524	0986435525	0986435533
0986435543	0986435544	0986435560	0986435571	0986435575
0986435576	0986435636	0986AD1047	0986AD1048	/

2) Injector Solenoid Valve O-ring Matching Information

Vehicle Brand	Car Model	Engine Model	OE Number
RENAULT	420 Premium Route	dCi 06.23.56 B43	50 10 412 093
AGRALE	8500 E-tronic	4.12 TCE	/
DODGE	Ram 2500 5.9	/	/
AGRALE	7215	Maxx Force 6.0A	/

3) Injector Solenoid Valve O-ring's Common Writing Methods

F00RJ00220, F 00R J00 220, MF00 RJ0 0220, F00RJ00 220, F00 RJ00220, F 00RJ00220,

1.3. F00RJ00220 Injector Solenoid Valve O-ring Parameters

Injector Solenoid Valve O-ring Adaptation System: [Common Rail System](#)

Injector Solenoid Valve O-ring Series: [0445120 Series](#)

Injector Solenoid Valve O-ring Type: [Electromagnetic](#)

1.4. F00RJ00220 Injector Solenoid Valve O-ring Specifications And Dimensions

Injector Solenoid Valve O-ring Size: [Diameter: 1.4mm](#) [Inner diameter: 24.7mm](#) [Outer diameter: 27.5mm](#)

Single Injector Solenoid Valve O-ring Weight: [1g](#)

Injector Solenoid Valve O-ring With Packaging Weight: [10g](#)

Injector Solenoid Valve O-ring Quality: [China Made New](#)

Injector Solenoid Valve O-ring Packaging Size: [11cm* 10cm *1cm](#)

Injector Solenoid Valve O-ring Type: [High Pressure Common Rail Injector Solenoid Valve O-ring](#)

Injector Solenoid Valve O-ring Minimum Order Quantity: [100 pieces](#)

1.5. F00RJ00220 Injector Solenoid Valve O-ring Quality Control

1) Injector Solenoid Valve O-ring Testing

All parts of the injector solenoid valve O-ring have undergone electrical characteristics testing, precision testing, high temperature testing, low temperature testing, withstand pressure testing, leakage testing, durability testing, and various working conditions testing.

2) Injector Solenoid Valve O-ring Installation


In addition, the injector solenoid valve O-ring production and installation process is quality controlled. Our company strictly follows the standard product installation data and product installation steps for installation, such as injector solenoid valve O-ring stroke test, injector solenoid valve O-ring solenoid valve tightening torque, injector solenoid valve O-ring nozzle tightening torque.

3) Injector Solenoid Valve O-ring Inspection

The factory inspection of the injector solenoid valve O-ring has undergone three inspections: full inspection, random inspection, and batch inspection. Different brands of test benches are used to test the same injector solenoid valve O-ring for more than three times for factory inspection, and the fuel injector installation testing environment are progressed in dust-free workshop.

1.6. F00RJ00220 Injector Solenoid Valve O-ring Customization Service

- 1) **Injector Solenoid Valve O-ring Customization Service Coverage:** Meet OEM manufacturers' customization needs for shell engraving, logo engraving, injector solenoid valve O-ring internal packaging, injector solenoid valve O-ring external packaging and labels, etc.

NO.	1
Picture	
Name	Injector Solenoid Valve O-ring Packaging

2) Injector Solenoid Valve O-ring Customization Service Requirements:

The purchase quantity of customized [injector solenoid valve O-ring](#) is not less than 10 pieces.





The purchase quantity of customized [injector solenoid valve O-ring boxes](#) is not less than 1000 pieces.

⚠ When the customized products involve the need of specify logo, the OEM manufacturer is asked to provide trademark authorization and the sample of logo image file.

⚠ Once the customized injector solenoid valve O-ring is sold, it can't be returned or exchanged if there is no quality problems.

1.7. F00RJ00220 Injector Solenoid Valve O-ring Parts List And Packaging Size

1) Injector Solenoid Valve O-ring Parts List

NO.	1	2	3
Picture			
Name	Injector Solenoid Valve O-ring Assembly	Injector Solenoid Valve O-ring Diameter	Injector Solenoid Valve O-ring Inner Diameter
Description	Injector solenoid valve O-ring part number: F00RJ00220	Diameter: 1.4mm	Inner Diameter: 24.7mm
NO.	4	/	/
Picture		/	/

Name	Injector Solenoid Valve O-ring Outer Diameter	/	/
Description	Outer Diameter: 27.5mm	/	/

⚠ Minors are prohibited from using the injector solenoid valve O-ring assembly, O-ring, nozzle protective cover, injector solenoid valve O-ring shell protective cover, oil return protective cover, VCI anti-rust bag, and bubble bag to avoid personal injury.

⚠ O-rings and nozzle washer shim are one-time installation accessories and need to be replaced when installed again.

⚠ The nozzle protective cover, injector solenoid valve O-ring shell protective cover, and oil return protective cover are recyclable accessories and can be reused.

⚠ VCI anti-rust bags and bubble bags are non-degradable materials, please dispose of them properly after using.

⚠ The injector solenoid valve O-ring and the installation part duct must be treated with appropriate sealing oil during installation.

2) Injector Solenoid Valve O-ring Packaging Box Size




Pic No.1

NO.	Name	Injector Solenoid Valve O-ring Packaging Size (cm)
1	Injector solenoid valve O-ring packaging	11*10*3

1.8. **F00RJ00220** Injector Solenoid Valve O-ring Testing Standards and Certificates

■ We can provide the factory quality inspection test report of each injector solenoid valve O-ring to ensure that each injector solenoid valve O-ring delivered meets the engine performance indicators.

BOTEN		测试报告		4.05.2019 10:42:09																																									
<div style="display: flex; justify-content: space-between;"> 承办单位: _____ </div>																																													
<div style="display: flex; justify-content: space-between;"> 电话: _____ 地址: _____ </div>																																													
<div style="display: flex; justify-content: space-between;"> 传真: _____ 检测人: _____ </div>																																													
<div style="display: flex; justify-content: space-between;"> 客户地址: _____ </div>																																													
<div style="display: flex; justify-content: space-between;"> 电话: _____ 送检单位: _____ </div>																																													
<div style="display: flex; justify-content: space-between;"> 传真: _____ 客户姓名: _____ </div>																																													
<div style="display: flex; justify-content: space-between;"> 检测地址: _____ </div>																																													
<div style="display: flex; justify-content: space-between;"> 客户名称: _____ </div>																																													
<div style="display: flex; justify-content: space-between;"> 型号/零件号: _____ </div>																																													
<div style="display: flex; justify-content: space-between;"> 检测时间: _____ </div>																																													
<h3 style="margin: 0;">检测结果</h3>																																													
<div style="display: flex; justify-content: space-between;"> 检测器型号: C90002-6511 </div>																																													
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">检测项目</th> <th style="width: 20%;">参考范围</th> <th style="width: 20%;">检测结果</th> <th style="width: 20%;">判定标准</th> <th style="width: 10%;"></th> </tr> </thead> <tbody> <tr> <td>LEAK TEST:</td> <td>≤ 2</td> <td>0.5</td> <td>20.0 ± 1.0</td> <td>✓</td> </tr> <tr> <td>Back:</td> <td>≤ 2</td> <td>0.5</td> <td>20.0 ± 1.0</td> <td>✓</td> </tr> <tr> <td>WAFER:</td> <td>≤ 2</td> <td>127.5 ± 10.0</td> <td>0.0</td> <td>✗</td> </tr> <tr> <td>Max:</td> <td>201.5</td> <td>218.5 ± 14.4</td> <td>0.0</td> <td>✗</td> </tr> <tr> <td>TL:</td> <td>28.0</td> <td>25.0 ± 0.5</td> <td>0.0</td> <td>✓</td> </tr> <tr> <td>LL:</td> <td>14.1</td> <td>15.7 ± 0.8</td> <td>0.0</td> <td>✓</td> </tr> <tr> <td>VE:</td> <td>0.0</td> <td>0.0 ± 0.0</td> <td>0.0</td> <td>✓</td> </tr> </tbody> </table>						检测项目	参考范围	检测结果	判定标准		LEAK TEST:	≤ 2	0.5	20.0 ± 1.0	✓	Back:	≤ 2	0.5	20.0 ± 1.0	✓	WAFER:	≤ 2	127.5 ± 10.0	0.0	✗	Max:	201.5	218.5 ± 14.4	0.0	✗	TL:	28.0	25.0 ± 0.5	0.0	✓	LL:	14.1	15.7 ± 0.8	0.0	✓	VE:	0.0	0.0 ± 0.0	0.0	✓
检测项目	参考范围	检测结果	判定标准																																										
LEAK TEST:	≤ 2	0.5	20.0 ± 1.0	✓																																									
Back:	≤ 2	0.5	20.0 ± 1.0	✓																																									
WAFER:	≤ 2	127.5 ± 10.0	0.0	✗																																									
Max:	201.5	218.5 ± 14.4	0.0	✗																																									
TL:	28.0	25.0 ± 0.5	0.0	✓																																									
LL:	14.1	15.7 ± 0.8	0.0	✓																																									
VE:	0.0	0.0 ± 0.0	0.0	✓																																									
<div style="display: flex; justify-content: space-between;"> 检测日期: _____ </div>																																													
<div style="display: flex; justify-content: space-between;"> 检测地点: _____ </div>																																													
<div style="display: flex; justify-content: space-between;"> 检测人员: _____ </div>																																													
<div style="display: flex; justify-content: space-between;"> 检测单位: _____ </div>																																													

Pic No.2

1.9. F00RJ00220 Injector Solenoid Valve O-ring Warranty Instructions

1) Product Warranty Conditions And Instructions

It is necessary to provide pictures, videos, or test reports tested by the injector solenoid valve O-ring inspection equipment when the injector solenoid valve O-ring is abnormal during use as evidence to feed back to the salesman. Abnormal conditions are properly explained such as: 1.Smoke, 2. Engine shake, 3. Difficulty starting the engine, 4. Engine noise, 5. Oil leakage etc.

2) Injector Solenoid Valve O-ring Warranty Coverage

- ① After customer receives the F00RJ00220 injector solenoid valve O-ring within 15 days , if there is a performance failure and the product has no damage on surface, customer can choose to replace it or repair it;
- ② If the F00RJ00220 injector solenoid valve O-ring has performance problems during the warranty period (3 months), and it is confirmed to be product's problems after being tested, you can contact our salesmen to replace the same model or a reworked product with the same performance for free;
- ③ If the injector solenoid valve O-ring shell has obvious scratches, it can only be repaired and it will be

returned as it is if the product is confirmed to be fault-free.

⚠ Tips: For products not covered by warranty, our company can provide paid maintenance services. For products after paid repaired, the same performance problem will have a free warranty period within 3 months from the date of repairing.

3) Injector Solenoid Valve O-ring Is Not Covered By Warranty

- ① The warranty period has expired.
- ② Injector solenoid valve O-ring failure caused by high temperature, high pressure, humidity, rain and snow, saline-alkali land, earthquake, and used in abnormal environment.
- ③ Customer disassembles or repairs the injector solenoid valve O-ring personally resulting in damage to the injector solenoid valve O-ring.
- ④ Injector solenoid valve O-ring damage caused by man-made reasons (throwing, strong magnetic field magnetization, set fire).
- ⑤ Injector solenoid valve O-ring failure or injector solenoid valve O-ring damage caused by non-injector solenoid valve O-ring design, technology, manufacturing, quality and other issues.
- ⑥ Injector solenoid valve O-ring failure due to system pressure exceeding system approved pressure.
- ⑦ Injector solenoid valve O-ring failure caused by system voltage exceeding approved voltage.
- ⑧ Injector solenoid valve O-ring failure caused by impurities (water, lead, aluminum powder, iron powder, sulfide) in the system fuel exceeding the standard requirements.
- ⑨ Injector solenoid valve O-ring failure caused by not installing according to the tightening torque specified in the vehicle engine maintenance manual (the tightening torque is too large or too small).
- ⑩ Injector solenoid valve O-ring failure caused by not following the installation angle specified in the vehicle engine maintenance manual.
- 11 Injector solenoid valve O-ring failure caused by not following the cleaning requirements specified in the vehicle engine maintenance manual.
- 12 Injector solenoid valve O-ring failure caused by failure to replace consumable parts as specified in the vehicle engine maintenance manual.
- 13 Injector solenoid valve O-ring failure caused by not complying with the intake system fit clearance and exhaust system fit clearance requirements specified in the vehicle engine maintenance manual.
- 14 Failure to replace the consumable parts and the fitting clearance of the oil inlet system pipeline and the injector solenoid valve O-ring connection in accordance with the fuel intake system specified in the vehicle engine maintenance manual.

1.10. F00RJ00220 Injector Solenoid Valve O-ring Manufacturer

Injector Solenoid Valve O-ring Manufacturer: Shenzhen Shumatt Technology Co., Ltd

2. F00RJ00220 Injector Solenoid Valve O-ring Technical Support

2.1. F00RJ00220 Injector Solenoid Valve O-ring Utilized Location

Example: The code of the injector solenoid valve O-ring is as follows:

NO.	Name
A	Injector Solenoid Valve O-ring



Pic No.3

2.2. **F00RJ00220** Injector Solenoid Valve O-ring Installation Precautions

- 1) The replacement of the injector solenoid valve O-ring must strictly follow the electrical system, the approved pressure of the low-pressure fuel intake system, the approved pressure of the high-pressure fuel circuit system, and fuel system replacement consumables requirements (including the low-pressure fuel circuit system filter and the high-pressure fuel circuit) specified in the vehicle engine maintenance manual.
- 2) Replacement of wearing parts of the fuel system, cleaning requirements for the connection between the fuel system and the injector solenoid valve O-ring, the fitting clearance of the injector solenoid valve O-ring connection, the installation angle and tightening torque of the injector solenoid valve O-ring, the fitting clearance of the intake system, and the fitting clearance of the exhaust system to ensure the service life of the engine and the normal operation of the injector solenoid valve O-ring.
- 3) When installing the injector solenoid valve O-ring on the engine, it is necessary to clean the engine block, cylinder head and other parts connected to the injector solenoid valve O-ring, and ensure that there is no dust, carbon deposits, water, rust spots, etc.
- 4) Before installing, check whether the injector solenoid valve O-ring washer shim has been replaced and installed on the injector solenoid valve O-ring.
- 5) When installing the injector solenoid valve O-ring, apply lubricant between the injector solenoid valve O-ring, fuel nozzle sealing washer shim and O-ring.
- 6) Without replacing new washer shim can lead to: deformation of the tight cap of nozzle, deformation of nozzle, deformation of nozzle orifice, oil leakage and air leakage, which will cause serious damage to the injector solenoid valve O-ring and nozzle to break and cause damage to the engine.
- 7) When installing the injector solenoid valve O-ring on the engine, please carefully check the components related to the installation of the injector solenoid valve O-ring, such as the injector solenoid valve O-ring pressure plate, screw, injector solenoid valve O-ring rod and other accessories are not deformed, and install it in strict accordance with the operation steps of the engine maintenance

manual.

- 8) It is forbidden to operate the bare injector solenoid valve O-ring for a long time in an environment with serious dust pollution and corrosion to iron products.
- 9) It is forbidden to operate the bare injector solenoid valve O-ring for a long time in a strong magnetic field environment.

2.3. Reasons for F00RJ00220 Injector Solenoid Valve O-ring Not Working Normally

- 1) There is air in the oil circuit of the engine fuel system.
- 2) Vehicle injector solenoid valve O-ring oil supply system is not normal.
- 3) Engine common rail system oil leakage or pressure limiting valve damage.
- 4) There is a short circuit, cutting out and poor contact in the wiring harness connected to the injector solenoid valve O-ring of the vehicle.
- 5) The long-term placement of the injector solenoid valve O-ring causes the anti-rust oil to solidify, and the internal components are stuck or the oil holes are blocked.

⚠ Before installing, carefully check whether other components in the common rail system are damaged so as to prevent the injector solenoid valve O-ring from not working properly after being replaced.

2.4. Causes of F00RJ00220 Injector Solenoid Valve O-ring Being Damaged

- 1) Didn't operate properly according to engine maintenance manual during disassembly or installation, resulting in damage to the injector solenoid valve O-ring .
- 2) The fuel oil used for the vehicle does not meet the standard cause damage to the injector solenoid valve O-ring, such as: the water content in the fuel oil exceeds the standard, iron powder, aluminum powder, sulfide impurities exceed the standard, etc.
- 3) The engine is not regularly maintained according to the engine maintenance manual (please refer to the vehicle maintenance manual for the maintenance mileage). For example, failure to replace the lubricating oil of the engine system for a long time will cause abnormal wear of the engine, excessive exhaust gas volume or a large amount of carbon deposits inside the engine. The filter is not replaced during maintenance or the replaced filter cannot reach the original filter standard. all above reasons can cause damage to the injector solenoid valve O-ring.
- 4) The abrasion of the oil pump produces iron powder and aluminum powder enter the injector solenoid valve O-ring and cause damage to the injector solenoid valve O-ring.
- 5) The deformation and abrasion of fuel tank result in iron powder or aluminum powder entering the injector solenoid valve O-ring and causing damage to it.
- 6) The injector solenoid valve O-ring is damaged due to replacement or adjustment of the relevant parts of the injector solenoid valve O-ring. For example, the valve clearance does not meet the standard after the engine is repaired, the replacement or modification of the wiring harness connected to the injector solenoid valve O-ring fails to meet the original standard.
- 7) The engine is overheated and overloaded for a long time working results in damage to the injector solenoid valve O-ring.
- 8) The injector solenoid valve O-ring will be damaged naturally at the end of its working life.
- 9) The injector solenoid valve O-ring is magnetized (injector solenoid valve O-ring parts' magnetic exceeded) causing the injector solenoid valve O-ring to not work properly.

⚠ Before replacing the injector solenoid valve O-ring, please check the engine parts carefully according to the engine maintenance manual to avoid the injector solenoid valve O-ring being damaged again after

replacement.

2.5. F00RJ00220 Injector Solenoid Valve O-ring Storage Standards

1) Choose a Suitable Storage Place

The warehouse and cargo yard where the injector solenoid valve O-rings are stored should be kept clean and dry, and away from the factory buildings that generate harmful gases and dust; do not mix with acid, alkali, salt and other substances; the storage place should have a good drainage system; the cargo yard should be flattened with gravel or furnace ash etc. to enhance the water permeability of the surface layer to keep the reservoir area dry.

2) Strict Storage Requirements

Strict inspections should be carried out when the injector solenoid valve O-rings are put into storage, the surface cleaning work should be done well to remove water traces, oil stains, ash and other dirt, remove the rust and do anti-rust treatment in time. Packaged injector solenoid valve O-rings must be protected from damage.

3) Keep The Warehouse Dry And Do Moisture-proof Work

The relative humidity is usually below 70% for the injector solenoid valve O-rings placed in the room, and the corrosion of the injector solenoid valve O-rings is significantly reduced.

Injector solenoid valve O-rings must be stored in the warehouse, and they are forbidden to store in the same warehouse with commodities with high water content.

4) Stack Properly

After the injector solenoid valve O-ring is exposed to rain, the corrosion rate will increase significantly. The purpose of sealing is to isolate the injector solenoid valve O-ring from rainwater and humid air, so the warehouse window should be checked in time to avoid rainwater entering the warehouse.

If the injector solenoid valve O-ring package is damaged, it should be repaired or replaced; when the package is damp, the packaging material should be dried; if the original anti-corrosion and oil applied at the factory is found to be damaged or dried up, it should be cleaned and re-applied oil in time.

⚠ It is forbidden to leave the injector solenoid valve O-ring exposed in the air for a long time.

⚠ It is forbidden to store acid, alkali, salt and other substances together with the injector solenoid valve O-ring.

⚠ The unpacked injector solenoid valve O-ring must be rust-proof during secondary storage.

2.6. F00RJ00220 Injector Solenoid Valve O-ring Technical Support Obtaining Methods

- 1) Injector Nozzle Technical Data: <https://www.injectorpart.com/download/>
- 2) Injector Nozzle Technical Videos: <https://www.injectorpart.com/videos/>
- 3) Injector Nozzle Encyclopedia: <https://www.injectorpart.com/category/news/encyclopedia/>

3. F00RJ00220 Injector Solenoid Valve O-ring Purchase And Delivery

3.1. F00RJ00220 Injector Solenoid Valve O-ring Purchase And Payment Term

Payment Method: T/T, Paypal, Alipay, WeChat

⚠ Please contact our salesmen for specific payment information.

3.2. F00RJ00220 Injector Solenoid Valve O-ring Main Sales Markets

Main Sales Markets Of Injector Solenoid Valve O-rings: Asia, Europe, North America, South America, Africa etc.

3.3. F00RJ00220 Injector Solenoid Valve O-ring Declaration Requirements

We can assist customers to provide the following documents for import customs clearance: contract, invoice, packing list, bill of lading, insurance policy, certificate of origin, etc.

3.4. F00RJ00220 Injector Solenoid Valve O-ring Shipping Ways

Destination in China areas: SF Express, Debon Express, the corresponding logistics company can be provided according to customer requirements in special cases.

Destinations out of China's areas: DHL, UPS, FedEx, TNT air, ocean or other shipping methods required by customers.

3.5. F00RJ00220 Injector Solenoid Valve O-ring Delivery Time

Delivery Time: Send out within 3 – 7 working days after receiving payment (Except for special products and special cases).

3.6. F00RJ00220 Injector Solenoid Valve O-ring Logistics Time for Destination Out of China's Areas

DHL Logistics Time:

Country or Region of Departure	Hong Kong, China	Other Countries or Regions of Asia	Australia and New Zealand	Europe	America	Other Countries
China's Mainland	7 Days	7 Days	8 Days	8 Days	8-12 Days	7-10 Days

UPS Logistics Time: Country or Region of Departure: China's Mainland

Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time	Country of Destination	Estimated Arrival Time
Japan	3 Days	UK	5-7 Days	Egypt	5-7 Days
Turkey	5-7 Days	Singapore	3 Days	Switzerland	5-7 Days
Bahrain	5-7 Days	Latvia	7-10 Days	New Zealand	7-10 Days
Sri Lanka	5-7 Days	Thailand	3 Days	Austria	5-7 Days
Romania	5-7 Days	Vietnam	3-5 Days	Estonia	5-7 Days
Malaysia	3-5 Days	Israel	5-7 Days	Mexico	7-10 Days
France	5-7 Days	America	5-7 Days	United Arab Emirates	5-7 Days
Italy	5-7 Days	Netherlands	5-7 Days	Bengal	7-10 Days
Lebanon	5-7 Days	Philippine	3-5 Days	Greece	7-10 Days
South Korea	3 Days	Spain	5-7 Days	Myanmar	5-7 Days
Canada	5-7 Days	Germany	5-7 Days	Saudi Arabia	7-10 Days
Portugal	5-7 Days	Australia	5-7 Days	South Africa	7-10 Days
Denmark	5-7 Days	Belgium	5-7 Days	Ukraine	7-10 Days
India	7-10 Days	Qatar	7-10 Days	Poland	5-7 Days
Indonesia	3-5 Days	Morocco	7-10 Days	Pakistan	7-10 Days
Kuwait	7-10 Days	/	/	/	/

⚠ The logistics time is for reference only, subjects are according to the actual arrival.

3.7. F00RJ00220 Injector Solenoid Valve O-ring Shipping Package

Domestic express packaging: Usually wrapped in waterproof scotch tape.




International express packaging: Wrapped with waterproof yellow tape after wrapping the black protective film.

Pallet Shipping: Use fumigation free and recycling trays that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties for the outside, also, the products can be packaged according to customers' requirements.

⚠ The packing tray is made of plastic and can be recycled.

⚠ Transparent tape, yellow tape, black wrapping protective film, white wrapping protective film are non-degradable materials, please dispose of them properly.

⚠ Minors are prohibited from using transparent tape, yellow tape, black wrapping protective film, and white wrapping protective film to avoid personal injury.

No.	1	2	3
Image			
Name	Domestic Express Packaging	International Express Packaging	Pallet Shipping
Description	Wrapped by transparent tape	Wrapped with yellow tape after wrapping black protective film	Use pallet that meet export requirements, and use white wrapping protective film to wrap and bind with cable ties

4. Company Information





Pic No.4


4.1. Company Introduction


 **Mobile Phone/WeChat:** +86-13410541523


 **Hong Kong Mobile Phone:** +852-67653519

 **Tel:** +86-755-23215133

 **Shenzhen Office:** 11-12, Floor 14, Building 13, Qinchengda Building, Exit A, Honglang North Subway Station, Bao'an District, Shenzhen, China Mainland

 **Shenzhen Office:** Exit C, Qiao Touxu Metro Station, No. 66 Chongqing Road, Fuhai Avenue, Bao'an District, Shenzhen, China Mainland

 **Hong Kong Office:** Jianfa Street Industrial Zone, Tuen Mun, New Territories, Hong Kong, China

 **After-Sales Service Address:** Please contact our salesmen to obtain and provide the corresponding product maintenance reasons (Reference: [1.9. F00RJ00220 Injector solenoid valve O-ring Warranty Instructions](#).)

4.2. Contact Information

Name	WeChat/ WhatsApp
Ruby	+86-13410541523

5. Copyright Statement

All content on www.injectorpart.com is sourced from and belongs to Shenzhen Shumatt Technology Co., Ltd. www.injectorpart.com has been authorized to use this content. Shenzhen Shumatt Technology Co., Ltd. holds all rights to the "[FOORJ00220](#) Injector solenoid valve O-ring Technical Instruction." Any reproduction, distribution, or public display of this material must clearly acknowledge Shenzhen Shumatt Technology Co., Ltd. as the source. Unauthorized use or failure to comply with these conditions will constitute a violation of the "Copyright Law of the People's Republic of China" and other relevant international laws and regulations.